

AK4500 Camera Compatibility List (WIFI Control)

Camera brand/model	Lens	Photo	Video	Follow focus	Zoom in&out	ISO	EV	WB	Switch photo/video	Keyboard firmware version on gimbal	Camera firmware	Note for Wifi Connection	
SONY	α9	12-44G	√	√	×	×	√	×	√	×	ak4500_ajb_sony_v1.2.6 and above	---	Enter the interface of smartphone control
	α7 III	16-50	√	√	×	√	√	×	√	×	ak4500_ajb_sony_v1.2.6 and above	---	---
	α7R III	16-50	√	√	×	×	√	√	√	×	ak4500_ajb_sony_v1.2.6 and above	---	---
	α7S II	16-50	√	√	×	√	×	√	×	×	ak4500_ajb_sony_v1.2.6 and above	---	---
	α7R II	NA	√	√	×	×	×	√	×	×	ak4500_ajb_sony_v1.2.6 and above	---	---
	α7 II	FE 4/16-35	√	√	×	×	×	√	×	×	ak4500_ajb_sony_v1.2.6 and above	---	---
	α7	FE 4/16-35	√	×	×	×	×	√	×	×	ak4500_ajb_sony_v1.2.6 and above	---	---
	α7S	16-35	√	√	×	×	×	√	×	×	ak4500_ajb_sony_v1.2.6 and above	---	---
	α7R	16-35	√	√	×	√	×	√	×	×	ak4500_ajb_sony_v1.2.6 and above	---	---
	RX100M4	2.8-4.5	√	√	×	√	√	√	√	×	ak4500_ajb_sony_v1.2.6 and above	1.0.0	---
	RX100M5	F1, 8	√	√	×	√	×	√	×	×	ak4500_ajb_sony_v1.2.6 and above	1.0.2	---
	RX100 M5A	F1, 8	√	√	×	√	√	√	√	×	ak4500_ajb_sony_v1.2.6 and above	Ver. 1.00	Enter the interface of smartphone control
	RX100M6	2.8-4.5	√	√	×	√	√	√	√	×	ak4500_ajb_sony_v1.2.6 and above	---	---
	α5100	16-50	√	√	×	√	×	√	×	√	ak4500_ajb_sony_v1.2.6 and above	---	---
	α6000	16-50	√	×	×	√	×	√	×	×	ak4500_ajb_sony_v1.2.6 and above	---	---
	α6300	28-70	√	√	×	√	√	√	√	×	ak4500_ajb_sony_v1.2.6 and above	V2.0.0	---
		16-50	√	√	×	√	√	√	√	×	ak4500_ajb_sony_v1.2.6 and above	V2.0.1	---
α6400	16-50	√	√	×	√	√	√	√	×	ak4500_ajb_sony_v1.2.6 and above	Ver. 1.00	Enter the interface of smartphone	
α6500	28-70	√	√	×	√	×	√	×	×	ak4500_ajb_sony_v1.2.6 and above	---	---	

RX0	NA	√	√	√	×	√	√	√	√	ak4500_ajb_sony_v1.2.6 and above	1.1.1	Enter the interface of smartphone	
FDR-X3000R	NA	√	√	×	×	×	√	√	√	ak4500_ajb_sony_v1.2.6 and above	---	---	
HDR-AS50R	NA	√	√	×	×	×	√	√	√	ak4500_ajb_sony_v1.2.6 and above	---	---	
QX1	20	√	√	×	√	√	√	√	√	ak4500_ajb_sony_v1.2.6 and above	---	---	
RX1RII	NA	√	×	×	√	×	√	×	×	ak4500_ajb_sony_v1.2.6 and above	---	---	
WX500	3.5-6.4	√	√	×	√	×	√	×	×	ak4500_ajb_sony_v1.2.6 and above	Ver. 1.00	---	
HX90	3.5-6.4	√	√	×	√	×	√	×	×	ak4500_ajb_sony_v1.2.6 and above	Ver. 1.00	---	
Canon	EOS 80D	NA	√	√	√	×	√	√	√	ak4500_ajb_canon_v1.2.6 and above	---	---	
	EOS 6D	NA	√	×	√	×	√	√	√	×	ak4500_ajb_canon_v1.2.6 and above	---	---
	EOS 6D Mark II	24-70	√	√	√	×	√	√	√	√	ak4500_ajb_canon_v1.2.6 and above	---	---
	EOS 5D Mark IV	24-105 24-70	√	√	√	×	√	√	√	√	ak4500_ajb_canon_v1.2.6 and above	---	---
	EOS 70D	16-35mm f/2.8L II	√	×	×	×	√	√	×	×	ak4500_ajb_canon_v1.2.6 and above	Ver. 1.1.1	---
	EOS 77D	24-70mm f/2.8L USM	√	√	√	×	√	√	×	√	ak4500_ajb_canon_v1.2.6 and above	Ver. 1.0.2	---
	EOS R	24-70mm f/2.8L USM	√	√	×	×	√	√	×	√	ak4500_ajb_canon_v1.2.6 and above	Ver. 1.0.0	---
	EOS 200D	18-55	√	√	√	×	√	√	√	√	ak4500_ajb_canon_v1.2.6 and above	---	---
M50	NA	√	√	×	×	×	×	×	√	ak4500_ajb_canon_v1.2.6 and above	---	---	
Panasonic	DMC-LX100	24-150	√	√	√	√	√	√	√	k4500_ajb_panasonic_v1.2.64 and above	---	---	
	DMC-LX10	NA	√	√	√	√	√	√	√	k4500_ajb_panasonic_v1.2.64 and above	---	---	
	DC-ZS70GK	NA	√	√	√	√	√	√	√	k4500_ajb_panasonic_v1.2.64 and above	---	---	
	DC-ZS220GK	24-360	√	√	√	√	√	√	√	k4500_ajb_panasonic_v1.2.64 and above	---	---	
	DMC-GH4	25mm F1.4	√	√	√	×	√	√	√	√	k4500_ajb_panasonic_v1.2.64 and above	---	---
	DC-GF9XGK	12-32	√	√	√	√	√	√	√	√	k4500_ajb_panasonic_v1.2.64 and above	---	---

Panasonic	DC-GF9KGK	12-32	√	√	√	×	√	√	√	√	k4500_ajb_panasonic_v1.2.64 and above	Ver. 1.1.1	---
	DC-GH5SGK-K	25mm F1.4	√	√	√	×	√	√	√	√	k4500_ajb_panasonic_v1.2.64 and above	Ver. 1.0.2	---
		35-100	√	√	√	×	√	√	√	√	k4500_ajb_panasonic_v1.2.64 and above	Ver. 1.0.0	---
	DC-GX9KGK-K	12-32	√	√	√	×	√	√	√	√	k4500_ajb_panasonic_v1.2.64 and above	---	---
	DC-GF10KGK	12-32	√	√	√	×	√	√	√	√	k4500_ajb_panasonic_v1.2.64 and above	---	---
	DMC-ZS110	M mode(25-250)	√	√	√	√	√	×	√	√	k4500_ajb_panasonic_v1.2.64 and above	Ver.1.2	---
		S mode(25-250)	√	√	√	√	√	√	√	√	k4500_ajb_panasonic_v1.2.64 and above	Ver.1.2	---
		A mode(25-250)	√	√	√	√	√	√	√	√	k4500_ajb_panasonic_v1.2.64 and above	Ver.1.2	---
		P mode(25-250)	√	√	√	√	√	√	√	√	k4500_ajb_panasonic_v1.2.64 and above	Ver.1.2	---
	DMC-GX85	M mode (H-H020A)	√	√	√	×	√	×	√	√	k4500_ajb_panasonic_v1.2.64 and above	Ver.1.2	---
		S mode (H-H020A)	√	√	√	×	√	√	√	√	k4500_ajb_panasonic_v1.2.64 and above	Ver.1.2	---
		A mode (H-H020A)	√	√	√	×	√	√	√	√	k4500_ajb_panasonic_v1.2.64 and above	Ver.1.2	---
		P mode (H-H020A)	√	√	√	×	√	√	√	√	k4500_ajb_panasonic_v1.2.64 and above	Ver.1.2	---
	GH5	M mode (H-HS12035)	√	√	√	×	√	√	√	√	k4500_ajb_panasonic_v1.2.64 and above	Ver.2.3	---
		S mode (H-HS12035)	√	√	√	×	√	√	√	√	k4500_ajb_panasonic_v1.2.64 and above	Ver.2.3	---
		A mode (H-HS12035)	√	√	√	×	√	√	√	√	k4500_ajb_panasonic_v1.2.64 and above	Ver.2.3	---
P mode (H-HS12035)		√	√	√	×	√	√	√	√	k4500_ajb_panasonic_v1.2.64 and above	Ver.2.3	---	